

1. Check the Subfloor

Place a level in multiple directions within the pocket to ensure the subfloor is level. If the floor is more than 1/8" out of level, it must be leveled before installation.

2. Position the Base

Place the base in the framed alcove. Set the wall panels aside.

3. Verify Level and Plumb

Use a level along both the horizontal and vertical reveals of the base to ensure it's plumb and level.

4. Prepare for Adhesive or Mat

Tilt the base forward or upside down to expose the pocket and support rungs.

- a. Option A: Apply construction adhesive along the front threshold and on each support rung.
- b. Option B: Apply adhesive along the threshold and on the floor perpendicular to the rungs, with ~3" spacing between adhesive lines.
- c. Option C: If using a black mat, cut it to fit and place it in the pocket. The mat serves as a sound barrier.

5. Install the Drain

Attach the drain fitting to the base.

6. Set the Base

Return the base to the upright position and place it in the pocket, ensuring the drain aligns with the plumbing.

7. Weigh Down the Base

If adhesive is used, place at least 120 lbs of weight (e.g., three 5-gallon buckets of water) on the base. Follow the adhesive manufacturer's recommended set time.

8. Check Stud Walls

Ensure stud walls are plumb. Shim where necessary.

9. Install Back Wall

Place the back wall so it seats over the base pins.

10. Secure Back Wall

Insert one screw in the center of the top horizontal flange to hold the back wall in place.

11. Prepare Plumbing

Drill necessary holes in the side wall for plumbing.

12. Install Valve Wall

Engage the valve wall into the back wall corner clips. Angle the panel as needed to fit around plumbing.

13. Optional Waterproofing

Apply silicone along seams before seating the panel, if additional waterproofing is desired.

14. Set Valve Wall

Rotate the wall over plumbing until flush with the base and tight against the studs.

15. Install Non-Valve Wall

Repeat the valve wall process for the remaining wall (angling optional).

16. Secure Wall Panels

Pre-drill and fasten panels to studs:

- a. Every 16" along vertical flanges
- b. Once per stud along horizontal flanges

Begin with the back wall.

17. Seal Seams

Apply tile caulk as needed. Follow local codes and ensure venting is provided if required.

Cleaning: It is recommended that general cleaning be performed using EverFab BathBrite cleaning solution. Avoid abrasive cleaning products as they may remove the glossy finish and make subsequent cleaning difficult