

INSTALLATION INSTRUCTIONS

- 1** Clean surface with alcohol or soapy water, wiping away any excess with a dry cloth
- 2** Place the endcap in the shower corner where the side wall meets the floor at the desired distance from the opening of the shower
- 3** Outline the endcap using a pencil
- 4** Mark along the inside edges of the underside of the endcap
- 5** Repeat the previous steps with the other endcap on the other side wall
- 6** Using a straight edge or string, draw a line across the shower opening connecting the inside edges of the endcap outlines
- 7** Apply at least (2) 1/4" beads of silicone adhesive along the length of the shower to within 1/2" of each of the vertical side walls
- 8** Beginning at the silicone bead on one end, firmly press the EverDam onto the silicone using the pencil marks as a guide, gently stretching the dam as you press
- 9** Press and stretch the EverDam across the entire opening of the shower and cutoff any rubber portion of the EverDam that extends within 1/2" of the vertical side wall
- 10** Apply E600 adhesive along the back of the endcap, around the edges, and inside the front slot
- 11** Press the endcaps down into the corners where you marked previously covering the ends of the rubber portion of the EverDam
- 12** Remove any excess pencil markings using alcohol and allow the dam to cure for approximately 6 hours before using